


Refrigerador Whirlpool WRX735SDBM00






Refrigerador Whirlpool WRX735SDBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10814198	Tech Sheet
	W10422734	Use & Care Guide
	W10729263	Energy Guide
2	12961401	Tube, Water
3	12698403	Plate, Pivot
4	B5759655	Gasket
5		Cover, Top Hinge
		Left Hand
	W10337634	White
	W10337647	Black
	W10337648	Grey
		Right Hand
	12962302W	White
	12962302B	Black
	12962302AP	Grey
6		Cover, Fill Tube
	12981401W	White
	12981401B	Black
	12981401AP	Grey
7	12961602	Cover, Control Box
8	M0108107	Clamp, Tube
9	12992602	Screw
10		Hinge, Top
	12963204ED	Left Hand
	12963205ED	Right Hand
11	489470	Screw
12	12990511	Screw
13	W10316403	Wedge, Spacer (Left Hand & Right Hand)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	12992403	Screw
15		Hinge, Center
		Left Hand
	W10740148	White
	W10740149	Black
	13000001AP	Grey
		Right Hand
	W10740144	White
	W10740145	Black
	13000002AP	Grey
16	W10367522	Slide, Mullion Vent
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18	W10827867	Knob, Vent Slide
19		Plug, Button
	A3076901	Black
20	W10709365	Screw
21		Shim, Top Hinge
	12999501	Left Hand
	12999502	Right Hand
22		Grille, Toe
	W10534154	White
	W10534153	Black
	W10534155	Grey
23	W10296541	Lid, HV Control Box
24	W10316401	Wedge, Spacer (Left Hand & Right Hand)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
25	12990702	Screw
26		Cabinet (Not A Servicable Part)
27	W10226427	Control, Electronic (Power Supply)
28	12990302	Screw
29	12957801	Gasket, Control Box
30	W10270394	Cover, Unit
31	W10141622	Brake, Roller
32	W10614933	Board, HV Control
33		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
34		Assembly, Secondary Mullion
	W10831971	White
	W10831969	Black
	W10831970	Grey
35	W10843353	Assembly, LED Light Module
36	W10820998	Housing, Module
37	W10492234	Brace, Mullion
38	W10311721	Mullion, Secondary






Refrigerador Whirlpool WRX735SDBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	3400065	Screw (Stainless)
3	W10311756	Lens, Refrigerator LED
4	W10587287	Module, LED Light
5	W10555984	Assembly, Air Grille
6	12466103	Switch, Rocker
7	W10118194	Lid, Enclosure
8	W10632157	Housing, Refrigerator LED
9	W10118193	Enclosure, Water Valve Connector

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10444033	Tube, Water
11	12960101	Cover, Upper Water Tank
12	12960301	Cover, Filter
13	12960001	Cover, Lower Water Tank
14	W10735404	Filter, Water
15	12955901	Bracket, Filter Base
16	W10309869	Cover, Wiring
17	W10334463	Bracket, Water Tank and Valve
18	W10657242	Assembly, Water Tank and Head (Includes Bypass Cartridge)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	12664501	SP Cartridge, Bypass
20	W10349187	Valve, Water Inlet






Refrigerador Whirlpool WRX735SDBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	A3189392	Gasket, Foam
3	12002497	Gear
4	12990501	Screw
5	W10802332	Shaft, Rack
6	12570701	Socket, Light
7	12815301	Cover, Thermistor
8	12990521	Screw
9	W10820003	Lamp, Led
10	W10277466	Foil, Housing
11	W10308421	Cover, Evaporator
12	12990511	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13		Bracket, Door Slide
	W10330991	Left Hand
	W10330993	Right Hand
14	W10315248	Module, Light
15	12956601	Clip, Fan Motor
16	12466111SP	Switch, Light
17	12990504	Screw
18	B8381501	Gasket, Drain
19	W10120018	Slide, Door
20	A3189396	Gasket
21		Adapter, Side
	W10284682	Left Hand
	W10284683	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
22	12959901	Grille, Air
23	12951401	Shroud, Evaporator
24	12986101	Blade, Fan
25	12951101	Grommet, Fan Motor
26	W10252866	Motor, Evaporator
27	W10662407	Assembly, Drain Funnel
28	M0500703	Seal
29	12791417SP	Thermistor






Refrigerador Whirlpool WRX735SDBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u> <u>Description</u>
1	Door, Refrigerator
	Left Hand
	13107323W White
	13107323B Black
	13107324S Stainless
	Right Hand
	13107319W White
	13107319B Black
	13107319S Stainless
2	W10323808 Bucket, Upper
3	W10212139 Bucket, Small
4	12990521 Screw
5	W10224961 Bucket, Gallon

<u>Illus.</u> <u>No.</u>	<u>Part No.</u> <u>Description</u>
6	12990513 Screw
7	W10460893 Screw
8	Gasket, Door
	W10830276 White
	W10830277 Black
	W10830274 Grey
9	Handle, Door
	W10356566 Stainless
10	Nameplate
	W10391355 White
	W10393265 Grey
11	W10511930 Waterline, Door
12	W10287601 Seal, Ice Chute

<u>Illus.</u> <u>No.</u>	<u>Part No.</u> <u>Description</u>
13	Mullion, Door
	W10311759 White
	W10311758 Black
	W10311757 Grey
14	Closure, Door
	12028505W White
	12028505B Black
	12028505AP Grey
15	Stop, Door
	12968202W White
	12968202B Black
	12968202AP Grey
16	12996601 Clip, Bushing






Refrigerador Whirlpool WRX735SDBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	13107111W	White
	13107111B	Black
	13107111S	Stainless
2		Gasket, Door
	W10443321	White
	W10436253	Black
	W10714545	Grey
3	W10293682	Bin, Lower

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10802333	Shaft, Rack
5	W10348249	Basket, Upper
6	W10146439	Divider, Upper Basket
7		Gear
	W10474716	Left Hand
	W10474715	Right Hand
8		Rack, Side
	W10516603	Left Hand
	W10516602	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
10		Bracket, Door Slide
	W10330991	Left Hand
	W10330993	Right Hand
11		Handle, Door
	W10719666	Stainless
12	W10460893	Screw






Refrigerador Whirlpool WRX735SDBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw
2	12825803	Blade, Fan
3	W10480111	Basepan
4	12990511	Screw
5	2319835	Grommet, Condenser
6	W10795418	Tube, Discharge
7	W10276647	Motor, Evaporator (Includes Heater Harness, Defrost Thermostat and Thermistor)
8	W10655368	Pan, Drain
9	W10622701	Screw
10	12729123	Heater, Defrost
11	W10798748	Device, Start
12	W10216075	Strap, Bale
13	W10137529	Grommet, Condenser
14	W10622099	Extension, Drain Tube
15	12477102	Roller
16	12992101	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10806346	Grommet, Compressor
18	W10346415	Condenser
19	W10281329	Clip, Drier
20	W10292803	Tray, Drip
21	12990702	Screw
22	W10313899	Evaporator
23	A3189397	Gasket, Foam
24	W10609117	Motor, CondenserFan
25	10428101	Clip, Heater
26	W10679214	Harness, Unit (Includes Power Cord)
27	W10177049	Drier
28	W10775170	Compressor
29	10623002	Clip, Evaporator
30	12477202	Axle, Roller
31	W10189184	Shroud, CondenserFan
32	W10350564	Capacitor
33	W10236396	Strap, Compressor
34	W10334458	Connector, WaterTube

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
35	W10815863	Clip, Condenser
36	2169104	Sealer, Insulation
Following Parts Not Illustrated		
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 5.50 oz. (R-134A)






Refrigerador Whirlpool WRX735SDBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12883508SP	Shelf, Glass
2		Glide, Snack Pan
	W10194031	Left Hand
	W10194032	Right Hand
3	12990302SP	Screw
4	W10319333	Pan, Snack (Includes Handle)
5	W10818645	Divider, Sliding
6	12885501	Shelf, Mini Stationary
7		Door, Pantry
	13107112W	White
	13107112B	Black
	13107112S	Stainless
8		Gasket, Pantry
	W10443325	White
	W10436255	Black
	W10443326	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	12883507	Shelf, Glide Out
10		Adapter, Pantry
	W10666362	Left Hand
	W10666363	Right Hand
11	W10277360	Gear, Spur
12		Cover, Gear
	W10284709	Left Hand
	W10294414	Right Hand
13	W10272364	Screw
14	W10460893	Screw
15	W10802341	Shaft, Rack
16		Ladder, Side
	W10251968	Left Hand
	W10251965	Right Hand
17	W10277361	Collar, Gear
18	W10801677	Pan, Pantry
19	W10273464	Ladder, Center

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
20		Handle, Door
	W10719666	Stainless
21	12990513	Screw
22	12990512	Screw
23	W10818644	Divider, Pantry
24	W10296571	Glass, Pantry Shelf
25	12466104	Switch, Rocker
26		Rail, Pantry
	W10311723	Left Hand
	W10311726	Right Hand
27	12227305WD	Brace, CrisperCover
28	W10331298	Rail, Rear Pantry
29	12990521	Screw
30		Cover, Pantry Rail
	W10311725	Left Hand

Refrigerador Whirlpool WRX735SDBM00






Refrigerador Whirlpool WRX735SDBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2		Assembly, UI
	W10521642	Stainless
3		Wall, Dispenser False
	W10215699	White
	W10233560	Black
	W10299897	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Assembly, Pad (Includes Blue Light)
	W10353846	White
	W10353847	Black
	W10353848	Grey
5	W10238083	Assembly, LED
6	W10353552	Assembly, Seperator
7	2316647	Assembly, Spigot Body
8	W10339578	Guide, Ice

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9		Dispenser, Tray
	W10267869	White
	W10267870	Black
	W10299895	Grey
10		Tray, Dispenser Slide
	W10267860	White
	W10267861	Black
	W10267863	Grey
11	W10254277	Cover, Board





Refrigerador Whirlpool WRX735SDBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10562191	Assembly, Ice Bin
2	W10121282	Inlet, Blower
3	W10309863	Scroll, Blower
4	W10308033	Motor, Fan
5	W10123444	Wheel, Blower
6	12956603	Clip, Fan Motor
7	W10151687	Grommet, Fan Motor
8	W10309864	Divider, Ice Box
9	12920001	Gasket, Damper

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10309868	Motor, Auger
11	W10196393	Damper, Control
12	W10309866	Assembly, Solenoid
13	W10118612	Liner, Divider
14	12990511	Screw
15	W10346971	Bracket, Solenoid
16	W10465946	Washer
17	63052A001	Yoke, Ice Dispenser
18	W10312691	Assembly, Impinger

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10377151	Assembly, Icemaker
20	W10378254	Arm, Shutoff
21	W10351019	Extension, Shutoff Arm
22	W10460383	Cover, Front
23	W10404016	Harness, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key