



FOUR DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:


WRX735SDHW00 (White)

WRX735SDHB00 (Black)

WRX735SDHV00 (Black Stainless)

WRX735SDHZ00 (Monochromatic Stainless Steel)

REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10873263	Tech Sheet
	W10422734	Use & Care Guide
	W10920569	Energy Guide
2	12961401	Tube, Water
3	12698403	Plate, Pivot
4	B5759655	Gasket
5		Cover, Top Hinge
		Left Hand
	W10337634	White
	W10337647	Black
	W10337648	Grey
		Right Hand
	12962302W	White
	12962302B	Black
	12962302AP	Grey
6		Cover, Fill Tube
	12981401W	White
	12981401B	Black
	12981401AP	Grey
7	12961602	Cover, Control Box
8	M0108107	Clamp, Tube
9	12992602	Screw
10		Hinge, Top
	12963204ED	Left Hand
	12963205ED	Right Hand
11	489470	Screw
12	12990511	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10316403	Wedge, Spacer (Left Hand & Right Hand)
14	12992403	Screw
15		Hinge, Center
		Left Hand
	W10740148	White
	W10740149	Black
	W10740150	Grey
		Right Hand
	W10740144	White
	W10740145	Black
	W10740146	Grey
16	W10367522	Slide, Mullion Vent
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18	W10827867	Knob, Vent Slide
19		Plug, Button
	A3076901	Black
20	W10709365	Screw
21		Shim, Top Hinge
	12999501	Left Hand
	12999502	Right Hand
22		Grille, Toe
	W10534154	White
	W10534153	Black
	W10534155	Grey


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
23	W10296541	Lid, HV Control Box
24	W10316401	Wedge, Spacer (Left Hand & Right Hand)
25	12990702	Screw
26		Cabinet (Not A Servicable Part)
27	W10867574	Control, Electronic
28	12990302	Screw
29	W10914798	Gasket, Control Box
30	W10270394	Cover, Unit
31	W10141622	Brake, Roller
32	M0104106	Clip, Cord
33		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
34		Assembly, Secondary Mullion
	W10902088	White
	W10902087	Black
	W10902089	Grey
35	W10843353	Assembly, LED Light Module
36	W10820998	Housing, Module
37	W10492234	Brace, Mullion
38	W10311721	Mullion, Secondary

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR WRX735SDH




REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	3400065	Screw (Stainless)
3	W10311756	Lens, Refrigerator LED
4	W10866538	Module, LED Light
5	W10555984	Assembly, Air Grille
6	12466103	Switch, Rocker
7	W10118194	Lid, Enclosure
8	W10632157	Housing, Refrigerator LED

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10118193	Enclosure, Water Valve Connector
10	W10444033	Tube, Water
11	12960101	Cover, Upper Water Tank
12	12960301	Cover, Filter
13	12960001	Cover, Lower Water Tank
14	W10735404	Filter, Water
15	12955901	Bracket, Filter Base
16	W10309869	Cover, Wiring

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10334463	Bracket, Water Tank and Valve
18	W10657242	Assembly, Water Tank and Head (Includes Bypass Cartridge)
19	12664501SP	Cartridge, Bypass
20	W10913947	Valve, Water Inlet

REFRIGERADOR WRX735SDH




REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	A3189392	Gasket, Foam
3	12002497	Gear
4	12990501	Screw
5	W10802332	Shaft, Rack
6	12570701	Socket, Light
7	12815301	Cover, Thermistor
8	12990521	Screw
9	W10805744	Lamp, Led
10	W10277466	Foil, Housing
11	W10308421	Cover, Evaporator
12	12990511	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13		Bracket, Door Slide
	W10330991	Left Hand
	W10330993	Right Hand
14	W10315248	Module, Light
15	12956601	Clip, Fan Motor
16	12466111SP	Switch, Light
17	12990504	Screw
18	B8381501	Gasket, Drain
19	W10120018	Slide, Door
20	A3189396	Gasket
21		Adapter, Side
	W10284682	Left Hand
	W10284683	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
22	12959901	Grille, Air
23	12951401	Shroud, Evaporator
24	12986101	Blade, Fan
25	12951101	Grommet, Fan Motor
26	W10252866	Motor, Evaporator
27	W10662407	Assembly, Drain Funnel
28	M0500703	Seal
29	12791417SP	Thermistor


REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	5	W10355264	Bucket, Gallon	12	W10287601	Seal, Ice Chute
		Left Hand	6	12990513	Screw	13		Mullion, Door
	13107323W	White	7	W10460893	Screw		W10311759	White
	W10861096	Black	8		Gasket, Door		W10311758	Black
	W11022747	Black Stainless		W10830276	White		W10311757	Grey
	W11022772	Stainless		W10830277	Black	14		Closure, Door
		Right Hand		W10830274	Grey		12028505W	White
	13107319W	White	9		Handle, Door		12028505B	Black
	W10861098	Black		W10887621	White		12028505AP	Grey
	W11022757	Black Stainless		W10887620	Black	15		Stop, Door
	W11022776	Stainless		W10918272	Black Stainless		12968202W	White
2	W10355269	Bucket, Upper		W10874805	Stainless		12968202B	Black
3	W10355270	Bucket, Small	10	W10884773	Badge		12968202AP	Grey
4	12990521	Screw	11	W10511930	Waterline, Door	16	12996601	Clip, Bushing

REFRIGERADOR WRX735SDH



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


REFRIGERADOR WRX735SDH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	W11023065	White
	W11023033	Black
	W10920749	Black Stainless
	W11022780	Stainless
2		Gasket, Door
	W10443321	White
	W10436253	Black
	W10714545	Grey
3	W10293682	Bin, Lower
4	W10802333	Shaft, Rack

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10348249	Basket, Upper
6	W10146439	Divider, Upper Basket
7		Gear
	W10474716	Left Hand
	W10474715	Right Hand
8		Rack, Side
	W10516603	Left Hand
	W10516602	Right Hand
9		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10		Bracket, Door Slide
	W10330991	Left Hand
	W10330993	Right Hand
11		Handle, Door
	W10887633	White
	W10887632	Black
	W11024145	Black Stainless
	W10874811	Stainless
12	W10460893	Screw


REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	16	12992101	Screw	32	W10350564	Capacitor
2	12825803	Blade, Fan	17	W10806346	Grommet, Compressor	33	W10236396	Strap, Compressor
3	W10480111	Basepan	18	W10346415	Condenser	34	W10334458	Connector, Water Tube
4	12990511	Screw	19	W10281329	Clip, Drier	35	W10815863	Clip, Condenser
5	2319835	Grommet, Condenser	20	W10292803	Tray, Drip	36	2169104	Sealer, Insulation
6	W10795418	Tube, Discharge	21	12990702	Screw			
7	W10276647	Motor, Evaporator (Includes Heater Harness, Defrost Thermostat and Thermistor)	22	W10313899	Evaporator			FOLLOWING PARTS NOT ILLUSTRATED
8	W10655368	Pan, Drain	23	A3189397	Gasket, Foam	978025		Valve, Access
9	W10622701	Screw	24	W10609117	Motor, Condenser Fan	978026		Valve, Access
10	12729123	Heater, Defrost	25	10428101	Clip, Heater	978027		Valve, Access
11	W10798748	Device, Start	26	W10679214	Harness, Unit (Includes Power Cord)	978028		Valve, Access
12	W10216075	Strap, Bale	27	W10177049	Drier	978029		Valve, Access
13	W10137529	Grommet, Condenser	28	W10775170	Compressor	978030		Valve, Access
14	W10622099	Extension, Drain Tube	29	10623002	Clip, Evaporator	876764		Valve, Access
15	12477102	Roller	30	12477202	Axle, Roller			REFRIGERANT CHARGE
			31	W10189184	Shroud, Condenser Fan			4.50 oz. (R-134A)


REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10345310	Assembly, Shelf and Roller	11	W10277360	Gear, Spur	25	12466104	Switch, Rocker
2		Runner, Roller	12		Cover, Gear	26		Rail, Pantry
	W10346891	Left Hand		W10284709	Left Hand		W10311723	Left Hand
	W10346890	Right Hand		W10294414	Right Hand		W10311726	Right Hand
3	8281136	Screw	13	W10272364	Screw	27	W10385043	Runner, Channel
4	W10366647	Pan, Deli	14	W10460893	Screw	28	W10331298	Rail, Rear Pantry
5	W10818645	Divider, Sliding	15	W10802341	Shaft, Rack	29	12990521	Screw
6	W10329926	Shelf, Mini	16		Ladder, Side	30		Cover, Pantry Rail
7		Door, Pantry		W10251968	Left Hand		W10311725	Left Hand
	W11023061	White	17	W10277361	Collar, Gear	31	W10396909	Front, Deli Pan
	W10921835	Black	18	W10801677	Pan, Pantry			
	W10920753	Black Stainless	19	W10273464	Ladder, Center			
	W11022766	Stainless	20		Handle, Door			
8		Gasket, Pantry		W10887633	White			
	W10443325	White		W10887632	Black			
	W10436255	Black		W11024145	Black Stainless			
	W10443326	Grey		W10874811	Stainless			
9	W10329925	Shelf, Stationary	21	12990513	Screw			
10		Adapter, Pantry	22	12990512	Screw			
	W10666362	Left Hand	23	W10818644	Divider, Pantry			
	W10666363	Right Hand	24	W10296571	Glass, Pantry Shelf			


REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	4		Assembly, Pad (Includes Blue Light)			
2		Assembly, User Interface		W10353846	White			
				W10353847	Black			
	W10887493	Silver		W10353848	Grey			
3		Wall, Dispenser False	5	W10238083	Assembly, LED			
	W10215699	White	6	W10353552	Assembly, Seperator			
	W10233560	Black	7	2316647	Assembly, Spigot Body			
	W10299897	Grey	8	W10339578	Guide, Ice			
9		r, Tray		W10267869	White			
	W10299895	Nickel		W10267870	Black			
10		Tray, Dispenser Slide						
	W10267860	White		W10267861	Black			
				W10267863	Grey			
11	W10254277	Cover, Board						

REFRIGERADOR WRX735SDH



REFRIGERADOR WRX735SDH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10562191	Assembly, Ice Bin
2	W10121282	Inlet, Blower
3	W10309863	Scroll, Blower
4	W10308033	Motor, Fan
5	W10123444	Wheel, Blower
6	12956603	Clip, Fan Motor
7	W10151687	Grommet, Fan Motor
8	W10309864	Divider, Ice Box
9	12920001	Gasket, Damper

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10309868	Motor, Auger
11	W10196393	Damper, Control
12	W10309866	Assembly, Solenoid
13	W10118612	Liner, Divider
14	12990511	Screw
15	W10346971	Bracket, Solenoid
16	W10465946	Washer
17	63052A001	Yoke, Ice Dispenser
18	W10312691	Assembly, Impinger

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10300024	Assembly, Icemaker (Complete)
20	W10175514	Arm, Shutoff
21	W10351019	Extension, Shutoff Arm
22	W10290556	Cover
23	W10826037	Harness, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key