




REFRIGERATOR

MODELS:

WRX988SIBW00 (White)
WRX988SIBB00 (Black)
WRX988SIBM00 (Monochromatic Stainless)
WRX988SIBH00 (White Ice)
WRX988SIBE00 (Black Ice)







Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10503798	Tech Sheet
	W10505280	Owners Manual
	W10503800	Energy Guide
2	W10453401	Supply, Power
3	W10344432	Block, Pivot
4	W10505487	Gasket
5	W10589837	Board, Control
6	W10415341	Gasket, HV Box
7		Plug, Button
	A3076901	Black
8	W10141622	Brake, Roller
9	12992602	Screw
10		Hinge, Top
	W10248409	Right Hand
	W10248410	Left Hand
11	W10403208	Screw (White)
	W10403211	Screw (Black)
	W10403212	Screw (Grey)
12		Cover, Right Hinge
	W10248562	White
	W10407157	Black
	W10407158	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Cover, Left Hinge
	W10471615	White
	W10471617	Black
	W10471618	Grey
14	W10308751	Screw (Black)
15		Hinge, Center (Right)
	W10248433	White
	W10248702	Black
	W10248703	Grey
16	W10336736	Cover, Roller
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18	W10394076	Valve, Water
19		Assembly, Roller
	W10515762	Right Hand
	W10515763	Left Hand
20	12991302	Screw
21	12990701	Screw
22		Grille, Toe
	W10637668	White
	W10637669	Black
	W10637671	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
23	12992601	Screw
24		Hinge, Center (Left)
	W10248434	White
	W10248705	Black
	W10248706	Grey
25	W10141645	Screw
26	12990511	Screw
27	W10306786	Supply, Power LED
28	W10485658	Cover, Control Box
29	12466105	Switch, Light
30	W10577369	Cover, Unit
31	M0108107	Clamp, Tube
32	W10503562	Tube, Drain
33	W10505294	Coupler, Door
34	W10212137	Retainer, Door
35		Cabinet (Not a Servicable Part)
36	549193	Clamp, Power Cord
37	W10141645	Screw
38	12990302	Screw
39	W10277839	Lid, HV
40	W10678711	Tube, Water






Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	A3189392	Gasket, Foam
3	W10637153	Assembly, LED Light Module
4	W10513424	Cover, Evaporator
5	12990511	Screw
6	12956601	Clip, Fan Motor
7	C3680310V	Switch, Light

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	12990504	Screw
9	W10496613	Grille, Air (Freezer)
10	W10363507	Shroud, Evaporator Fan
11	12986101	Blade, Fan
12	12951101	Grommet, Fan Motor
13	W10514110	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10503250	Funnel, Drain
15	M0500703	Seal
16	B8381501	Gasket, Drain
17	W10405166	Cover, Thermistor
18	W10531268	Gasket, Dual Evaporator
19	W10280385	Thermistor






Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10657942	Housing, Water System
3	W10482107	Tube, Fill
4	W10679246	Reservoir, Water (Also Order Wire Tie Part 8567668 Quantity 5)
5	W10341329	Valve, Dual Water
6	W10238156	Housing, Water Filter
7	W10279854	Enclosure, Valve
8	W10669663	Cover, Water
9	2223877	Latch, Push
10	W10277949	Door, Filter Access
11	W10609378	Filter, Water
12	W10315189	Filter, Air
13	W10674102	Waterline, Valve To Hinge
14	W10554299	Heater, Fill Tube
15	12990518	Screw
16	W10598013	Cover, Icebox

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10492817	Assembly, Icebox (Foamed)
18	W10503486	Enclosure, Evaporator
19	W10525237	Pan, Drain
20	W10505516	Trim, Icebox
21	W10460280	Assembly, Blower
22	W10630535	Assembly, Evaporator
23	W10637153	Assembly, LED Light Module
24	W10673906	Motor, Fan (Also Order Fan Support #W10389152)
25	W10553630	Assembly, Fascia
26	C3680310V	Switch, Light
27	W10434481	Bracket, Reservoir
28	W10280983	Insulation
29	W10389152	Support, Fan
30	W10635022	Adapter, Icebox
31	W10503491	Retainer, Damper
32	W10503492	Support, Damper
33	W10248595	Damper, Electronic Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
34	W10438957	Cover, Thermistor
35	W10503500	Cover, Evaporator
36	W10465948	Gasket, Evaporator Enclosure
37	W10510863	Gasket, Drain Tube
38	W10320706	Gasket, Rear Return
38	W10280988	Gasket, Rear Supply
40	W10392172	Gasket, Fan
41	W10624930	Assembly, Air Tower
42	W10470981	Gasket, Damper
		Following Parts Not Illustrated
	W10537498	Harness, Evaporator Wire (Includes Thermistor)
	W10570599	Harness, Dual Valve
	W10578603	Harness, Refrigerator Lights






Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	W10545987	White
	W10545986	Black
	W10503829	Stainless
2		Door, Right
	W10545980	White
	W10545979	Black
	W10550669	Stainless
3	W10464016	Screw
4	W10549589	Door, Ice
5		Latch, Door
	W10681407	Left Hand
	W10681408	Right Hand
6		Mullion, Door
	W10698202	White
	W10698203	Black
	W10698204	Grey
7	12990204	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Handle, Door
	W10589564	White
	W10589563	Black
	W10572632N	Stainless
9	12990504	Screw
10		Bumper, Door
	W10407175	White
	W10407187	Black
	W10407188	Grey
11		Nameplate
	W10391355	White
	W10393265	Grey
12	W10460893	Screw
13	W10533404	Trivet, 2 Liter
14	W10674770	Bucket, Gallon
15	489214	Screw
16	W10347085	Gasket, Ice Door
17	W10245516	Clip, Tube
18	W10518658	Board, ReceiverCircuit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10258510	Cover, Receiver
20	3400065	Screw (Stainless)
21	W10258502	Cover, Emitter
22	W10258540	Slide, Icemaker Shut Off
23	W10518659	Board, Emitter Circuit
24	W10400825	Retainer, Ice Chute
25	W10347087	Gasket, Ice Chute
26	W10646855	Vent, Thermistor
27	W10258520	Door, Emitter
28	2198635	Spring, Door
29	2198634	Pin, Door
30		Gasket, Door
	W10545606	White
	W10545602	Black
	W10503817	Grey
31	W10499015	Tube, Water






Refrigerador Whirlpool WRX988SIBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw
2	2188935	Blade, Fan
3	W10570074	Baseplate
4	12990511	Screw
5	W10547687	Extension, Drain
6	W10391081	Assembly, ValveBody
7	W10303521	Sleeve
8	W10655371	Tray, Evaporator
9	W10216919	Screw, Shoulder
10	12729128	Heater, Defrost
11	W10154805	Assembly, InverterBox
12	W10248621	Clip, Condenser
13	12477102	Roller
14	12992101	Screw
15	W10413009	Grommet, Air Return
16	W10559262	Condenser
17	W10391376	Bracket, Valve
18	W10342573	Tray, Drip
19	W10141645	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
20	W10248589	Evaporator
21	W10364560	Coil, 3 Way Valve
22	2188875	Motor, Condenser
23	10428101	Clip, Heater
24	W10442270	Harness, Unit
25	W10286069	Drier
26	W10155907	Compressor
27	W10142294	Screw
28	12477202	Axle, Roller
29	W10406719	Shroud
30	W10630315	Cord, Power
31	W10278140	Cover, Bottom Unit
32	W10296661	Clip, Bottom Cover
33	W10491355	Gasket, Airdam
34	W10626970	Assembly, Suction Tube
35	W10514110	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)
36	W10236396	Strap, Compressor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
37	2215676	Cover, Terminal
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 5.50 oz. (R-134A)






Refrigerador Whirlpool WRX988SIBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10533406	Shelf, Tuck
2	W10698206	Assembly, Secondary Mullion
3	W10421495	Screw
4	W10509272	Crisper, Medium
5	W10509275	Crisper, Small
6	W10493545	Cover, Crisper
7		Door, Pantry
	W10546009	White
	W10546008	Black
	W10550670	Stainless
8		Gasket, Pantry
	W10545601	White
	W10518365	Grey
	W10545600	Black
9	W10533400	Shelf, Fixed
10		Adapter, Pantry
	W10667416	Left Hand
	W10667417	Right Hand
11	W10530295	Roller
12		Cover, Gear
	W10284709	Left Hand
	W10294414	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	12991702	Screw
14	W10277360	Gear, Spur
15	W10298176	Shaft, Rack
16	W10372170	Ladder, Side
17	W10277361	Collar, Gear
18	W10530656	Pan, Pantry
19	W10248516	Ladder, Center
20	12991401	Screw
21	W10423560	Screw
22	W10577906	Guide, Crisper
23	W10328402	Divider, Large Pantry
24	W10577907	Assembly, Floor
25	C3680310V	Switch, Light
26	W10537691	Heater, Pantry
27	W10530295	Roller
28	W10549991	Thermistor
29	W10518378	Cover, Connector
30	W10248967	Support, Rear
31	W10493549	Glass, Crisper
32	12702901	Pad, Glide
33	W10586081	Bin, Secondary Mullion
34	W10630283	Glass, Bin Upper

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
35	W10583890	Glass, Bin Lower
36	W10518036	Cover, Side Adapter
37		Handle, Door
	W10557414	White
	W10557415	Black
	W10557413N	Stainless
38	W10460893	Screw
39	W10637153	Assembly, LED Light Module
40	W10512203	Harness, Side Adapter
41		Assembly, User Interface
	W10503833	Stainless
	W10599145	Black
42	W10593207	Assembly, Produce Preserver
43	W10236512	Support, Front






Refrigerador Whirlpool WRX988SIBM00

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	W10547319	White
	W10547318	Black
	W10547320	Stainless
2		Handle, Door
	W10557414	White
	W10557415	Black
	W10557413N	Stainless
3	W10460893	Screw
4	W10503522	Shaft
5		Assembly, Bracket
	W10638293	Left Hand
	W10638294	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10650427	Bin, Lower
7	12990518	Screw
8	W10493169	Bin, Upper
9	W10248509	Clip, Shaft
10	W10507444	Divider, Lower
11	W10469177	Support, Pan
12	W10488124	Front, Upper Pan
13	489443	Screw (Stainless)
14		Adapter, Upper Pan
	W10619219	Left Hand
	W10619218	Right Hand
15	W10704091	Assembly, CenterPan

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Stop, Pan
	W10485089	Right Hand
	W10485096	Left Hand
17		Gasket, Door
	W10249094	White
	W10248748	Black
	W10248749	Grey







Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2		Assembly, User Interface
	W10590564	Silver
	W10590562	Black
3		Wall, Dispenser False
	W10606658	White
	W10606648	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Assembly, Pad
	W10473006	Cast Grey
	W10370592	Black
	W10473007	Tempest Grey
5		W10577864 Assembly, Seperator
6		W10435760 Guide, Ice
7		Tray, Drip
	W10606644	White
	W10606639	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Ring, Trim
	W10462438	White
	W10462439	Black
	W10402180	Chrome
9		W10470750 Assembly, LED






Refrigerador Whirlpool WRX988SIBM00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10347051	Plate, Ice Chute
3	2198628	Seal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10347120	Clip, Retainer
5	W10347114	Shaft, Motor
6	W10215646	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	W10347093	Assembly, Ice Container



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10498261	Assembly, Icemaker

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key