




Refrigerador Whirlpool WSR57R18DM

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10668406	Use & Care Guide
	W10574439	Energy Guide
	W10653921	Tech Sheet
2	3-80732-014	Screw
3	W10574323	Cover, Unit
4		Cover, Hinge
	2213360	White
	2254510	Grey
5	2261963	Assembly, Top Hinge

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Hinge Plate, Bottom
	W10574264	White
	W10574262	Grey
7		Plug, Hole
	W10520304	White
	W10520307	Grey
8		Roller Assembly
	W10515763	Left Hand
	W10515762	Right Hand
9	3400113	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10717194	Drain Tube
11	12991302	Screw
12		Cabinet (Not A Serviceable Part)
13	W10574325	Hinge Pin, Lower
14	W10141622	Brake, Roller
15		Grille, Toe
	W10534166	White
	W10534165	Grey
16	2150304	Roller
17	2179826	Axle, Rivet






Refrigerador Whirlpool WSR57R18DM

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10701911	Control Assembly
3	W10384183	Thermistor, Refrigerator Compartment
4	W10608692	Cover, Thermistor
5	W10574272	Air Tower

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	2-32164-001	Switch, Light
7	W10565137	Lamp, LED
8	W10569269	Lens, Control Box
9	W10581572	Crisper Cover, Top
10	W10569286	Shelf, Deep
11	W10591310	Crisper Cover, Bottom

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10654386	Crisper Pan, Top
13	W10574368	Gasket, Air Tower (Vertical)
14	W10574564	Gasket, Air Tower (Horizontal)
15	W10654387	Crisper Pan, Bottom
16	W10581574	Glass, Crisper






Refrigerador Whirlpool WSR57R18DM

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2314293	Thimble
2	W10371194	Bucket, Medium
	W10351081	Bucket, Small
3	W10628869	Bracket, Door Stop
4		Handle, Door
	W10635689	Stainless
5		Gasket, Door
	W10574474	White
	W10574476	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Door Assembly
	W10578906	White
	W10578907	Stainless
7		Nameplate
	W10481434	White
	W10481433	Grey
8	12557904	Retainer, Door
9	W10460893	Screw
10	12369502	Tray, Dairy

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	11 W10612074	Lid
	12 W10574673	Door, Pizza Shelf





Refrigerador Whirlpool WSR57R18DM

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10574307	Cover, Evaporator
2	W10574283	Evaporator
3	W10359880	Fan Motor
4	2169142	Blade, Fan
5	W10316428	Heater, Defrost
6	W10314195	Shield, Heat
7	W10574291	Drain Pan, Evaporator
8	W10574305	Gasket, Evaporator Cover
9	W10383615	Thermistor, Freezer Evaporator
10	W10572628	Wire Harness (Includes Power Cord)
11	13058002	Clip, Evaporator Motor
12	3-80732-014	Screw
13	W10150583	Grommet, Fan Motor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10591673	Compressor
15	W10350564	Capacitor
16	W10177049	Drier
17	W10574450	Shield, Capacitor
18	W10693200	Harness, Evaporator Fan
19	W10591671	Start Device
20	W10574470	Bale Strap
21	2183042	Grommet
22	W10142287	Bolt
23	489473	Screw
24	W10574571	Suction Tube
25	W10574281	Exchanger, Heat
26	W10574278	Pan, Compressor
27	549193	Clamp, Power Cord

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
28	W10574469	Shroud, Evaporator Fan
29	2315541	Bracket, Condenser Fan
30	2188875	Motor, Condenser
31	8533961	Screw
32	W10139483	Blade, Fan
33	W10574289	Condenser
34	W10248621	Clip, Condenser
35	W10142294	Screw
36	W10296661	Clip, Bottom Cover
37	W10574274	Cover, Evaporator Fan
		REFRIGERANT CHARGE 4.75 oz. (R-134A)

OPTIONAL PARTS (NOT INCLUDED)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	8171357	Graphite

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	80051	Brush Touch-up Kit Graphite
	W10134625	Apollo Grey (Bottle)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	8171358	Graphite

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key