


### Cajones y parrillas






# Refrigerador Whirlpool WT1870A00

<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Puerta ensamble refrigerador	LW10836814
2	Ensamble parrilla refrigerador	W10895170
3	Cajon legumbrero	W10884526
4	Cubierta cajon legumbrero	W10805888
5	Cajón de carnes	W10815714
6	Bin movil refrigerador	W10805890
7	Anaquelel fijo refrigerador	W10805892
8	Puerta ensamble congelador	LW10803960
9	Parrilla congelador	W10895169
10	Ensamble de hielo twist	*****
11	Barandillas congelador	W10824761
12	Barandilla refrigerador	W10245587
13	Placa marca Whirlpool	W10481433
14	Rieles del cajon de carnes	W10814193
15	Parrilla media refrigerador	W10895170
16	Perilla Congelador	W10833308
17	LED LAMP 120V E14	W10809513
18	Socket LAMP congelador	W10545295
19	Socket Light refrigerador	W10134764
20	LED - LAMP 120V E26	2311792
21	DIVIDER CRISPER PAN	*****

## Bisagras y Soportes






## Refrigerador Whirlpool WT1870A00

<b><u>No. Ilus.</u></b>	<b><u>DESCRIPCIÓN</u></b>	<b><u>No. de Parte</u></b>
<b>1</b>	Bisagra superior y pivote	W10300065
<b>2</b>	Bisagra inferior con nivelador	W10873479
<b>3</b>	Bisagra central y pivote	W10870325
<b>4</b>	Separador bisagra central	2166086
<b>5</b>	Bisagra inferior y pivote	W10873478
<b>6</b>	Separador bisagra inferior	W10873476
<b>7</b>	Soporte compresor	W10893124
<b>8</b>	Rollers traseros	2265358


## Sistema de sellado



← 2



← 7



6

5

1



← 3


← 4



## Refrigerador Whirlpool WT1870A00

<b><u>No. Ilus.</u></b>	<b><u>DESCRIPCIÓN</u></b>	<b><u>No. de Parte</u></b>
1	Charola de evaporacion	W10892733
2	Condensador	W10219349
3	protector termico (Combo Device)	W10796752
4	Capacitor	W10642075
5	Compresor con amortiguadores	W10743447
6	Filtro Deshidratador	W10669573
7	Arnes tomacorriente principal	W10846433

## Flujo de Aire y Controles






## Refrigerador Whirlpool WT1870A00

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Cubierta difusor de aire	W10570480
<b>2</b>	Hood And Foil Ensemble	W10570941
<b>3</b>	Arnes caja de control	W10846463
<b>4</b>	Soporte del Abanico	W10321162
<b>5</b>	Retenedor motor evaporador	2254454
<b>6</b>	Aspas para motor evaporador	2200509
<b>7</b>	Motor del abanico evaporador	W10188389
<b>8</b>	Cubierta evaporador ensamble	W10879733
<b>9</b>	Ensamble arnes congelador	W10846461
<b>10</b>	Ducto de Aire, Ensamble	W10868539
<b>11</b>	Ensamble evaporador	W10570565
<b>12</b>	Heater- defrost	W10570573
<b>13</b>	Base evaporador	W10570572
<b>14</b>	THERMOSTATO	W10511937
<b>15</b>	Cubierta de hielo seco	W10813581
<b>16</b>	BIMETAL	W10392132
<b>17</b>	Tarjeta	2303825
<b>18</b>	Perilla refrigerador	W10840263
<b>19</b>	Socket foco refrigerador	W10134764
<b>20</b>	LIGHT SHIELD	9791702
<b>21</b>	CONTROL BOX	W10848030



Refrigerador Whirlpool WT1870A00



<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Cubierta (Fascia) del Dispensador	W10812125
2	Palanca de Agua	W10812124
3	Tanque de agua	W10836554