


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool WTW7000DW0






## Lavadora Whirlpool WTW7000DW0

Guía	N.p.	Descripción
1	W10609549	Cap
2	W10625252	Washer washplate screw
3	W10447976	Washer drum shaft assembly
4	W10578861	Ring-tub
5	W10753364	Washer water-level pressure switch hose
6	W10609476	Washer washplate
7	W10447975	Washer clutch kit
8	W10006494	Washer clutch kit
9	W10564013	Washer spanner nut
10	W10586078	Washer spin basket
11	W10512161	Washer outer tub
12	W10614061	Washer wire harness, lower
13	W10005430	Clamp
14	8533943	Dryer screw
15	W10275082	Washer clutch kit
16	W10594082	Washer suspension rod kit
17	W10579778	Washer motor stator
18	W10256551	Bushing
19	W10447973	Washer clutch
21	W10447979	Washer motor rotor
22	W10636382	Screw
23	W10215093	Washer drain pump filter
24	W10644129	Screw

Lavadora Whirlpool WTW7000DW0



Literatura Parts



## Lavadora Whirlpool WTW7000DW0


Guía	N.p.	Descripción
1	W10682737	Installation
1B	W10607408	Technical sheet
1C	W10062957	Energy guide
2	W10635913	Top
3	W10631106	Lid
4	9724509	Washer lid bumper
5	8563964	Washer lid hinge arm
6	W10676603	Pad-sound ab
7	W10119828	Washer screw
8	W10142630	Washer hose clamp
9	W10594147	Lid hinge
9A	W10594148	Lid hinge
10	W10601839	Washer bleach dispenser (white)
11	W10630254	Washer lid lock bezel
12	W10708964	Bearing
13	90016	Washer wire harness retainer
14	W10648012	Washer lid lock assembly
15	W10273971	Washer screw
16	693995	Washer screw
17	W10697357	Washer cabinet (white)
18	W10724131	Brace
19	W10512626	Brace
20	WP489069	Appliance screw
21	W10387117	Nameplate
22	W10687506	Washer leveling leg
23	W10612644	Rear panel
24	W10414221	Sound absr
25	W10142728	Refrigerator screw



## Lavadora Whirlpool WTW7000DW0

Guía	N.p.	Descripción
26	W10676061	Wire shield
27	3400076	Washer power cord ground screw
28	W10339879	Washer cable tie
29	W10221546	Washer drain hose
30	W10280024	Washer drain hose u-bend bracket
31	356138	Hose clamp
32	9740848	Dishwasher screw
33	311932	Screw
34	W10688364	Absorber
35	8564458	Washer sound dampening
36	W10652930	Laundry center washer pump drain hose

Lavadora Whirlpool WTW7000DW0





## Lavadora Whirlpool WTW7000DW0


Guía	N.p.	Descripción
1	W10662254	Washer control panel (white)
2	W10631630	Console interface
2A	W10631629	Console interface
3	W10596717	Harns-wire
4	12990204	Refrigerator screw
5	8312709	Laundry appliance end cap clip
6	W10625688	Washer electronic control board
7	W10611544	Washer control panel cover, rear
8	W10219342	Screw
9	1157158	Appliance screw
10	W10726624	Washer control panel seal
11	W10479821	Washer power cord
12	3400076	Washer power cord ground screw, #10-3
13	W10632533	Washer dispenser drawer assembly
14	W10758829	Washer water inlet valve
15	9740848	Dishwasher screw
16	W10631226	Washer water inlet valve wire harness
17	W10568405	Speaker
18	WPW10109200	Dryer screw
19	W10601841	Washer dispenser bezel (white)
20	W10777950	Washer dispenser drawer
21	W10596694	Console fascia

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool WTW7000DW0








## Lavadora Whirlpool WTW7000DW0

Guía	N.p.	Descripción
1	W10581874	Washer drain pump
2	W10637932	Heat shield
3	W10142630	Washer hose clamp
4	8317496	Washer hose clamp
5	W10004910	Washer screw
6	W10622690	Washer tub-to-pump hose

Lavadora Whirlpool WTW7000DW0





## Lavadora Whirlpool WTW7000DW0


Guía	N.p.	Descripción
1	W10662254	Washer control panel (white)
2	W10631630	Console interface
2A	W10631629	Console interface
3	W10596717	Harns-wire
4	12990204	Refrigerator screw
5	8312709	Laundry appliance end cap clip
6	W10625688	Washer electronic control board
7	W10611544	Washer control panel cover, rear
8	W10219342	Screw
9	1157158	Appliance screw
10	W10726624	Washer control panel seal
11	W10479821	Washer power cord
12	3400076	Washer power cord ground screw, #10-3
13	W10632533	Washer dispenser drawer assembly
14	W10758829	Washer water inlet valve
15	9740848	Dishwasher screw
16	W10631226	Washer water inlet valve wire harness
17	W10568405	Speaker
18	WPW10109200	Dryer screw
19	W10601841	Washer dispenser bezel (white)
20	W10601851	Washer dispenser drawer

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool WTW7000DW0





## Lavadora Whirlpool WTW7000DW0

Guía	N.p.	Descripción
1	W10581874	Washer drain pump
2	W10637932	Heat shield
3	W10142630	Washer hose clamp
4	8317496	Washer hose clamp
5	W10004910	Washer screw
6	W10763259	Washer tub-to-pump hose