

Distribuidor Autorizado



SurteRápido.com

Venta de Refacciones
Electrodomesticas

MICROONDAS XO1410MD

MICROWAVE OVEN

XO1410MD



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

MICROONDAS XO1410MD

Guía	Refacción	Descripción
1	WG02L00464	PLATO
2	WG02L00480	RING ROTATING ASSY
3	WG02L00123	COVER WAVE GUIDE
5	WG02F01757	TT DRIVER
9	WG02F00735	HV CAPACITOR
10	WG02F00737	DIODO
11	WG02F02341	SPRING BUTTON
13	WG02F00214	CAPACITOR CLAMP
14	WG02F00455	ENSAMBLE PANEL DE CONTROL
15	WG02F01573	TARJETA
16	WG02F01023	MEMBRANE
19	WG02L00711	ASSY BRKT HINGE U
20	WG02F01149	MOTOR TRAY
20	WG02F11648	MOTOR TRAY
21	WG02F00616	H.V TRANSFORMER
22	WG02F01343	POWER CORD
22	WG02F12306	POWER CORD
24	WG02F01113	MONITOR SWITCH
24	WG02F11957	MONITOR SWITCH
26	WG02F01530	SWITCH
26	WG02F01530	SWITCH
27	WG02F00944	MAGNETRON
27	WG02F11552	MAGNETRON
28	WG02F01650	THERMOSTAT 160/95 V
29	WG02F02333	LAMP
29	WG02F12257	LAMP
30	WG02L00736	CUBIERTA EXTERIOR
34	WG02F00074	SEGURO TABLETA
35	WG02F02335	LEG
37	WG02L00713	BASE PLATE
38	WG02F00563	FUSE
41	WG02F00160	BUTTON DOOR OPEN
44	WG02L00008	ASS"Y CAVITY
46	WG02F00520	FILTER NOISE
48	WG02F00899	INTERRUPTOR PALANCA

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

MICROONDAS XO1410MD

Guía	Refacción	Descripción
49	WG02L00367	GUIDE FAN
50	WG02F00475	FAN
51	WG01F01662	MOTOR VENTILADOR
67	WG02F01244	PANEL CONTROL
71	WG02L00591	ENSAMBLE PUERTA
73	WG02L00721	GASKET DOOR
74	WG02L00436	PANEL DOOR
75	WG02A00242	MONTAJE DE BISAGRA
76	WG02A00243	SEGURO SPRING
77	WG02F00872	LATCH